Chandelier Installation

Tools Required:






Adjustable Wrench Philips Screwdriver

Before Installation


- 1. Please read these instructions before assembling or installing the product. **NOTE**: Installation by a licensed electrician is recommended.
- 2. Take out the fixture and the mounting package and make sure all parts are included. If any part is missing or damaged, please contact us.
- 3. All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken.
- 4. Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
- 5. **IMPORTANT**: Turn off the main power at the circuit breaker and place the wall switch or pull chain in the "OFF" position.
- 6. Do not use bulbs with wattage greater than specified on this fixture.

Parts List



| Part | Name | Quantity |
|------|-----------------------|----------|
| А | mounting rod | 1 |
| В | lock | 1 |
| С | canopy | 1 |
| D | mounting nut | 1 |
| E | main wire | 1 |
| F | chain | 1 |
| G | chain connector | 1 |
| Н | light fixture | 1 |
| I | sleeve | 8 |
| J | mounting strap | 1 |
| AA | wire connector | 2 |
| ВВ | ground wire | 1 |
| СС | lastic expansion pipe | 2 |
| DD | self-tapping screw | 2 |

Installation Guide



- 1. Shut off the power before installation.
- 2. Fix the mounting strap (J) to ceiling.
- 3. Feed the main wire (E) through the chain connector (G) and chain (F). Screw the chain connector (G) to the light fixture (H).
- 4. Feed the main wire (E) through the mounting nut (D), canopy (C), lock (B) and mounting rod (A). Then, screw the lock (B) to the mounting rod (A) and attach the canopy (C) to the mounting strap (J), fixing with mounting nut (D).
- Connect the wires with wire connectors(AA) to the corresponding wires in ceiling.
- 6. Put on the sleeves (I) and install the light bulbs (not included with the light fixture).
- 7. Turn on the power and test.

Troubleshooting

| Problem | Possible Cause | Corrective Action |
|-------------------------|-----------------------------------|---------------------------------|
| Fixture does not light. | Fixture may be wired incorrectly. | 1. Check wiring. |
| | 2. Worn or broken bulb. | 2. Replace bulb. |
| | 3. Lamp socket or LED transformer | 3. Replace lamp socket or |
| | (if applicable) may go bad. | LED transformer (if applicable) |
| Light bulb flickers. | Switch Contacts are bad. | 1. Replace the switch. |
| | 2. Wire connections are loose. | 2. Check wire connections. |
| | 3. Light bulb socket may go bad. | 3. Replace the socket. |